

# Using the U60 LEDs and Buttons

## Using the LEDs

The LEDs on the U60 provide an indication of its status and operation. The U60 has the LEDs:

| Label   | Name     | Description   |
|---------|----------|---|
| Service | Service  | The <b>Service</b> LED indicates the network status of the U60. |
| Rx      | Receive  | The <b>Rx</b> LED indicates packets being received.             |
| Tx      | Transmit | The <b>Tx</b> LED indicates packets being transmitted.          |